



Quick Reference Guide For DSC equipment

Arming: For “Quick” Arming: Stay Mode (when you are in the home): Press STAY and hold it for 2 seconds until the keypad beeps. This bypasses any motion sensors. Away Mode (when you are leaving the home): Press AWAY and hold it for 2 seconds until keypad beeps. This arms the entire system.

Disarming: Enter your four digit code. There is not a “Quick” Disarming feature.

Bypassing: Press *1 (the bypass light will flash). Next press the 2 digit zone # (01-32) to be bypassed. Next, press # to exit the bypass mode and return to a green ready light. Arm the system as normal.

Additional Codes: Press *5 and enter the 4 digit master code. Enter a number, 01-32, or 40 for the master code. Next, enter any four numbers you wish. Press # to leave this mode and return to the ready mode. NOTE: To erase a code, follow the same steps listed above, except instead of entering four new numbers, press the * button four times.

Door Chime: To turn the Door Chimes on or off, press and hold the CHIME button.

Smoke Detector: Enter your 4 digit code to disarm system if the smoke detector should go off. After your alarm has been deactivated, press the RESET button on your keypad to reset the smoke detection system.

Trouble: If the yellow trouble light comes on, press *2 and record the flashing number for trouble shooting. Next, call SDS at 1-800-594-0048 with the trouble code so we may assess the problem.

Testing: SDS recommends testing your system once a month. To do this, call our office at 1-800-594-0048.

Superior Detection Systems

8115 Isabella Lane

Suite 1

Brentwood, TN 37027

615-373-8330 or 800-594-0048

www.superiordetection.com